


Assemble Manual

Step 1


Select a flat ground for the tent, unpack the carton and check all the parts including tubes, tent and accessories... etc. are present as same as list.

Assemble the framework of rooftop by joining the portion (5.6.7.8.9.) together with poles (1.2.3). To ensure the screw and turn buckle fixed to every pole tightly .




Step 2

Attach one end of supported pole (4) to the joints (6.7)




Step 3

Cover the roof on the frame ,and attach it by the bungee balls properly ,take care of the tension of the bungee balls ,for if you use too many on one side of tent ,it may too tight to tie the other side of it .



Step 4


Attach the another supported poles to the joints , built-up the framework ,use the long peg to fix each pole into the ground and use the hook to fix the leg cover to the leg .



Assemble Manual


Step 5

spread the wall panel and door panel attach to framework by using the bungee cords clasping the frame to grommets that is construct over the wall panel and door panel to ensure stability. Also use the short pegs to fix the doors to the ground.



Step 6

The Guy lines clasp to each corner of tent and another end of line fix to ground by pegs.



Warning:

1. In order to avoid being rusted by air ,oil is covered on the surface of the pipes ,before set up the tent ,please remove the oil carefully frist to keep the cover clean.
2. Take note that the tent needs to be handled carefully to avoid damage.
3. Do not force the frame as they may be damage in the process.
4. Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.
5. The windows maybe a little bit sticky to each other ,when you unfold the windows ,please do as softly as you can .Or the windows maybe crack during the process.

Please select a suitable site for the tent to avoid the damage to underground sprinkler systems, water, gas or electrical lines.





















DANCOVER®

Big or Small we cover it all...

Nordre Strandvej 119 G
3150 Hellebæk
Denmark
Tel.: (+45) 70 26 76 20
Fax: (+45) 70 26 76 30







WWW.DANCOVERSHOP.COM

5m PE series Instruction

Part no.			5x4m	5x6m	5x8m	5x10m	5X12M
1	Frame pole		6	8	10	12	14
2	Frame pole		12	17	22	27	32
3	Leg		2	4	6	8	10
4	Leg		4	4	4	4	4
5	2-way connector		6	8	10	12	14
6	110° 3-way Connector		4	4	4	4	4
7	110° 4-way Connector		2	4	6	8	10
8	140° 3-way Connector		2	2	2	2	2
9	140° 4-way Connector		1	2	3	4	5
	Big peg		4	4	4	4	4
	Middle peg		6	8	10	12	14
	Small peg		28	32	36	40	44
	Bungeeball long		60	68	76	84	92
	Bungeeball short		22	22	22	22	22
	Rope		4	4	4	4	4
	Screw		42	58	74	90	106
	Hook		4	4	4	4	4
	Roof		1	1	1	1	1
	Sidewall		2	2	2	2	2
	Endwall		2	2	2	2	2


5 METER PARTY TENT GOUNDBAR SYSTEM

1. Part list


Item name		5x8m	5x10m	5x12m
No.10 1920mm long pipes		12	14	16
No.11: 200mm long connectors		4	4	4
No.12: 1060mm long pipes		2	2	2
Screw		22	26	30
Nut		22	26	30
Screw		8	8	8

2. Connector

Four way connector with screws:



Three way connector with screw;



3. Lay all pipes and connectors on the ground as the following picture shows, and connect them as pictures show, Tighten the screws afterwards.

